

Quick guide

Phonetracker Location Center 4 Free / Phonetracker Locator PC

The zipped file *PLC4F_PLGPRS.zip* contains two software applications.

a. Phonetracker Location Center 4 Free

This software application enables you to track a mobile object and show the location on a map.

b. Phonetracker Locator PC

This software application takes the location information from a connected GPS receiver and send them in certain intervals to the Phonetracker server through the internet. The server forwards those location information to the PC where the application **Phonetracker Location Center 4 Free** is running.

To uninstall the application **Phonetracker Locator PC** simply delete the whole folder. To uninstall the application **Phonetracker Location Center 4 Free** use the uninstaller.


Start to setup the application **Phonetracker Locator PC**.

You need:

- a (portable) PC like a netbook with OS Windows XP or above,
- a GPS receiver with NMEA compatible protocol,
- a (portable) Internet connection.


1) Setting up the application Phonertracker Locator PC

- I. Copy the unzipped file *Phonertracker_Locator_PC.exe* to a folder in any destination. An installation procedure is not necessary. No Registry entries will be made.
- II. Connect your GPS receiver and check the COM port with the Control Panel. Be sure that your GPS receiver sends GPS data in NMEA format.
- III. Start the application *Phonertracker_Locator_PC.exe* !
- IV. Choose the language with the flags right down.
- V. Choose the COM port of your GPS receiver and Baudrate if necessary..




Under the slider „NMEA data“ the GPS data will be shown. Even if you are not sure which COM port your GPS receiver uses please disconnect the device from the USB port and press the button „Update list of COM ports“. Now you see which COM port is missing on the current com port list.

Some GPS receiver need to get a command to start sending data in NMEA format. Press the button „Send command to GPS receiver“ to open a new window where you are able to enter the necessary command. The GPS receiver needs to send the „\$GPRMC“ message at all!




- VI. Move to the slider „Position information“. As soon as the GPS receiver sends reasonable data details regarding the position will be shown.



If the GPS data are valid press the button „Position...“ to show the current location on a map in a new window. Reasonable GPS data you discern on the green coloured globe at the lower toolbar. With the button „NMEA file“ you are able to use a present tracking file.

- VII. Move to the slider „TCP/IP data transmission“.




Please note the 16-digit hardware ID, choose a time interval between 30 and 120 seconds and press the button „Connect“ nearby „TCP/IP server“.

Now start the setup of the software application **Phonetracker Location Center 4 Free**.
You need:


- a (mobile) PC with OS Windows XP or above,
- a (mobile) Internet connection.

2) Setting up the application **Phonetracker Location Center 4 Free**


- Start the file *PTLC_ForFree_Setup.exe* and follow the installation instructions.
- Start the application **Phonetracker Location Center 4 Free**.
- Press the button „Setup“. Now the app checks if an Internet connection exists. If you are online, press the button „Next >“.



- Press the button „Activate Google Maps API“ and confirm to the licence agreement of Google Maps™. After that press „Next >“.




- Press on „User administration“ and enter the hardware ID from the app **Phonetracker Locator PC** as „Device ID“. Next press „Apply“ and „OK“ and „Next >“.



VI. Press „Register“ to connect the Phonetracker Server and then press „Next >“ and „Close“.



From now on the showed location in the application **Phonetracker Locator PC** will be refreshed in the preset time interval. For more details press „F1“.



Visit our WEB site www.phonetracker.de and www.gpstrackersoftware.com!